


AGES AND STAGES - GENERAL GUIDELINES

FRONT CARRY OUTWARD-FACING
 (~5 Months)
 Min. 14 lbs / 6.4 kg
 Max. 30 lbs / 13.6 kg

FRONT CARRY INWARD-FACING
 Min. 7 lbs / 3.2 kg
 & Min. 20 inches / 50.8 cm
 Max. 45 lbs / 20.4 kg

HIP CARRY
 (~6 Months)
 Min. 17 lbs / 7.7 kg
 Max. 45 lbs / 20.4 kg

BACK CARRY
 (~6 Months)
 Min. 17 lbs / 7.7 kg
 Max. 45 lbs / 20.4 kg



1 FOLLOW THESE EASY STEPS TO GET STARTED

1A Adjust the seat to your baby's height, using the velcro tabs

1B Position the head and neck support according to baby's age and activity

1C Adjust the carrier seat to face baby in or out, using the sliders


1D Loosen both shoulder straps

1E Push & Squeeze to unbuckle the shoulder straps if needed


2 - TIPS & TRICKS FOR THE RIGHT FIT

2 BABY POSITIONING CHECKLIST & TIPS


2A Baby close enough to kiss, high on your body




2B Deep seat with knees high




2C Spine in soft, rounded shape



2D Head supported at mid-ear level for babies 0-4 months and until baby has strong head and neck control.




2E Open airway & visible face at all times




3-10 - HOW TO USE THE CARRIER


3 HOW TO ATTACH THE CARRIER WAISTBELT




4 FRONT CARRY INWARD-FACING WITH CRISSCROSS "X" STRAPS




5 FRONT CARRY INWARD-FACING WITH PARALLEL "H" STRAPS




6 FRONT CARRY OUTWARD-FACING WITH CRISSCROSS "X" STRAPS




7 FRONT CARRY OUTWARD-FACING WITH PARALLEL "H" STRAPS




8 HIP CARRY



OMNI DELUXE



- 1 Hood Snap
- 2 Hood
- 3 Head & Neck Support Buttons
- 4 Pocket
- 5 Waistbelt Buckle
- 6 Safety Elastic
- 7 Lumbar Support
- 8 Chest Strap Buckle
- 9 Crossable Shoulder Straps
- 10 Head & Neck Support
- 11 Strap Indicator Markings
- 12 Shoulder Strap Buckle
- 13 Sliders for Seat Adjustment
- 14 Reflectivity
- 15 Velcro Tab for Seat Adjustment
- 16 Detachable Pouch Buckle



Omni Deluxe™ ALL-IN-ONE BABY CARRIER

Check out more tips and videos. Ergobaby.com

ergobaby

THE ERGO BABY CARRIER, INC.
 US: 2041 East Street, Suite B31
 Concord, California 94520
 +1 888 416 4888 | support@ergobaby.com

EU: Ergobaby Europe GmbH
 Gaußstraße 120, 22765 Hamburg, Germany
 +49 40 421 065 0 | customersupport@ergobaby.eu

UK: EBP Lifestyle Brands UK Ltd.
 275 New North Road, Islington L3 0JG
 London, N1 7AA, United Kingdom
 +44 203 3186 204 | customersupport@ergobaby.co.uk

